Flashers and Tower Lighting Controls

Tower and Obstruction Lighting Controls



SCR SERIES

Universal Lamp Alarm Relay





Wiring Diagram

BEACON LAMP CONNECTION DIAGRAM



V = Voltage B = Beacon Lamps SS = Selector Switch T = Toroid F = Flasher AXL = Auxiliary Load/Alarm Relay contacts

are isolated.

Description

The SCR series is a universal lamp alarm relay designed to sense the failure of flashing or steady incandescent beacon lamps or steady side lights. The toroidal current sensor provides isolation and allows monitoring of more than one line at a time. The SCR Series energizes when one or more lamps fail. It will monitor the operation of one to four side lights and up to four beacon lamps.

Operation

When a lamp fails, the SCR Series senses a decrease in current flow. After a fixed time delay, the LED glows and the two alarm outputs energize. The outputs and the LED are reset when the failed lamps are replaced and the current returns to the nominal setting, or when the input voltage is removed. The SCR will sense an open flasher, it will not sense a continuously ON flasher (see FB Series).

Features & Benefits

FEATURES	BENEFITS	
Toroidal current sensing	Provides isolation from the lighting circuit and allows monitoring of multiple lines simultaneously	
Monitors 1-4 side lights or up to 4 beacon lamps	Senses failed incandescent flashing beacon or steady obstruction lamps	
Isolated, 10A, SPDT alarm output plus one 1A, solid-state line voltage alarm output	Provides alarm indication and can also be used for remote monitoring of the lighting system	
Fixed trip delay (6s)	Prevents nuisance alarms	
Switch selectable number, voltage, and wattage of lamps	User selectable to meet wide application needs with one relay	

OBSTRUCTION LAMP CONNECTION DIAGRAM



V = Voltage SS = Selector Switch T = Toroid AXL = Auxiliary Load/Alarm OL = Obstruction Lamps

Relay contacts are isolated.

Ordering Information

MODEL	INPUT	LAMP TYPE
SCR430T	120VAC	Incandescent
SCR630T	230VAC	Incandescent

If you don't find the part you need, call us for a custom product 800-843-8848

© 2016 Littelfuse Protection Relays & Controls

www.littelfuse.com/scr

Flashers and Tower Lighting Controls

Tower and Obstruction Lighting Controls



Selection Range

SCR SERIES



a. Lamp Wattage - Select the lamp wattage of the lamps in use.

- b. Lamp Voltage Select the lamp voltage shown on the lamp (SCR430T)
- c. Lamps ON Select the number of lamps on during normal operation. Only one lamp switch at a time may be transferred to the right.

Programming Example



Example Shown: SCR430T-620 watts at 120 VAC lamps, two lamps are ON during normal operation.

STEP

1. Select lamp wattage: 116 or 620 watts

2. Select the number of lamps ON (1 thru 4) during normal operation. Only one lamp switch may be ON (RIGHT) at any time.

Specifications

Operation Lamp Monitoring **Capacity (in lamps)** 100W SCR430T 120VAC Lamps SCR630T 230VAC Lamps **Time Delay Trip Delay** Input **Input Voltage/Tolerance AC Line Frequency**

Output Line Voltage Output (Solid-state Rated)

Mechanical Mounting

Dimensions

Termination

Protection

Circuitry **Environmental Operating Temperature** Weight

116W 620W 700W 4 4 n/a 4 n/a 4

Factory fixed \approx 6s

4

n/a

SCR430T - 120VAC ±10% SCR630T - 230VAC ±10% 50/60Hz To operate a spare lamp or alarm

≤ 125W @ 120VAC Isolated Alarm Output (SPDT) 10A @ 240VAC or 30VDC resistive; 1/4 hp @ 125VAC; 1/2 hp @ 250VAC

> Two #6 (M3.5 x 0.6) screws **H** 88.9 mm (3.5"); **W** 63.5 mm (2.5"); **D** 44.5 mm (1.75") Screws with captive clamps for up to 14 AWG (2.45 mm²) wire

Encapsulated

-55° to 65°C ≅ 6.8 oz (193 g)